



Notes:

1. The redundant power connections to the TH-2 and receiver are for safety.
2. Use a "Y" lead if no spares are available on the receiver.
3. Twist all power cables coming from the BEC.
4. Flybarless gyro configuration shown.

Twin Rexx V2 Wiring Diagram

Rev. - 7/8/17

